

## 5. Deleting a Scheduled Timer (Future Recording)

- a. If you want to delete a scheduled recording or timer, press the DVR button. Select "My Recordings."



The "Dish on Demand" screen first appears. Then the "My Recordings" screen appears.

- b. Scroll up and select "Schedule."



The "Daily Schedule" screen appears.

- c. Scroll up and select "Timers."



The "Timers List" screen appears.

- d. Scroll to the left until the timer you would like to delete is highlighted and then press SELECT.



The "Timer Event" screen appears.

- e. Scroll up and select "Delete."



A warning message appears.

- f. Select "Yes."



The "Timers List" appears and the deleted schedule/timer will be gone.

## 1. Using Your DVR While Watching Live TV

### Pause TV

- a. If you are interrupted while watching TV, press PAUSE.



The program pauses for up to 1 hour.

### Resume watching

- b. When you would like to resume watching TV, press PLAY.



The program resumes.

### Skip back (10 seconds)

- c. If you missed something and want to see it again, press SKIP BACK to go backward 10 seconds at a time.



The program skips back 10 seconds at a time.

### Skip forward (30 seconds)

- d. Press SKIP FWD to go forward 30 seconds at a time.



The program skips forward 30 seconds at a time, until you reach live TV.

### View live TV

- e. If you want to view live TV, press VIEW LIVE TV.



The program goes to live TV.