

2. Recording a TV program

Record a program NOW

- a. If you are watching TV and want to begin recording that program, press **RECORD** and then select **"OK."**



The "rec" logo appears and recording will begin.

Record a program in the FUTURE

- b. If you want to schedule a recording for a program that takes place in the future, press **GUIDE**.



The Program Guide appears.

- c. Scroll through the Guide until the program that you want to record is highlighted and then press **SELECT**.



The "Create Timer" screen appears.

- d. Scroll through and select the Frequency you would like to use to record the program and then select **"Create Timer."**

FREQUENCY

All Episodes	Records all episodes, including re-runs.
New Episodes	Records only new episodes.
Once	Records the show only one time.



The attention screen appears. Then the Program Guide will appear with a record icon next to the program.

3. Watching a Recording

- a. If you would like to view a program that you previously recorded, press the **DVR** button.



The "Dish On Demand" screen appears.

- b. Select **"My Recordings."**



The "My Recordings" screen appears.

- c. Scroll through until the program you would like to watch is highlighted, and press **SELECT**.



The "DVR Event" screen appears. "Start" is highlighted.

- d. Select **"Start"** to play your recording.

4. Deleting a Recorded Program

- a. If you want to delete a recorded program, press the **DVR** button.

- b. Select **"My Recordings."**



The "Dish On Demand" screen first appears. Then the "My Recordings" screen appears.

- c. Scroll through until the program you would like to delete is highlighted and then press **SELECT**.



The "DVR Event" screen appears.

- d. Scroll down and select **"Delete."**



A warning message appears.

- e. Select **"Yes."**



A confirmation message appears.